

Easy-On Wireless Tail Lights

Battery Installation and Tail Light Training Instructions

Each Tail Light requires two standard “D” batteries. High-quality alkaline batteries are recommended for use in the Tail Lights.

Warning! Do not mix battery types in a Tail Light or the Remote Transmitter. This can result in damage to the unit or injury hazard to people.

Insert the new batteries, being careful to insert them with proper orientation (indicated by the polarity on the sticker). Wrap the provided elastic band around the battery holder retaining clips twice to provide additional support for the batteries.

****Important**:** Whenever you install the batteries in a Tail Light you must ‘retrain’ the Tail Light to connect to the remote transmitter and recognize its unique ‘serial number’, so that other Remotes in the vicinity cannot interfere with your Tail Lights.

Each time you install or re-set batteries in the Tail Lights, do the following simple steps:

1. Ensure there are no other Easy-On Wireless Tail Lights in the vicinity.
2. Install the batteries in both Tail Lights.
3. Turn on the Remote by pressing the ‘Power’ button (with the green circle).
4. Make sure the Remote is within a few feet of both lights. Depress the ‘Training’ button (with the square icon and radiating curves) for 1 to 2 seconds. The two ‘turn’ lights on the Remote will flash quickly, indicating the Remote is in ‘training’ mode.
5. When both Tail Lights are also flashing quickly (about 2 times a second), then the Tail Lights have been trained to the Remote.
6. Press the ‘Training’ button on the Remote again for 1 to 2 seconds to end the training mode.

The Tail Lights are shipped in a convenient storage box. When shipped, the metal back plate on each Tail Light is flipped so that the magnets are facing *inwards*- towards the inside of the enclosure. **After you install the batteries, re-attach the back plate so that the magnets are facing *outwards*.**

****Important**:** To maximize the battery life and better insure that your EasyOn Tail Lights are ready to go when you need them.

When you are done using the Tail Lights, *it is strongly recommended that you open the units and remove the batteries, then store them at least a foot away from the lights.* Storing the units with the batteries installed, or in close proximity to the powerful magnets, will drain power from the batteries over a period of a few months.

It is also recommended that when not in use, that you re-attach the back plate with the magnets facing inwards. This will help protect the magnets from picking up stray metallic objects.

When not in use, store the units in a cool, dry place.

(*We suggest that you print this page and place in the EasyOn storage box for easy reference)